

Carolina Wren Nesting Box Directions

by Bob Orthwein

1 x 8 board (actual size is $\frac{3}{4}$ x $7\frac{1}{2}$) that is 30" long will make this box.

You will need 16 screws or nails to assemble.

Mount box with two screws through the back of the box.

Dimensions

1 Top 7 $\frac{1}{2}$ wide x $6\frac{1}{2}$ deep (with 2 short and 1 long side routed for rain drip)

2 Sides 5 wide x $6\frac{1}{2}$ tall

1 Back 5 wide x $6\frac{1}{2}$ tall

1 Front $6\frac{1}{2}+$ wide x 4 tall (wide enough to go across the front of the box)

1 Bottom 5 wide x 4 deep (with each corner trimmed off for drainage)

